


PEAK HOUR ITM SUMMARY

#001 14th St & Bush Avenue

LOCATION#: 001	QTD PROJ#: 100158	AM PEAK: 745 AM
NORTH / SOUTH: 14th St	DATE: Thursday, September 23, 2010	MD PEAK: 1200 PM
EAST / WEST: Bush Avenue	VICINITY: San Pablo, CA	PM PEAK: 415 PM



AM COUNT 7:00AM TO 9:00AM MD COUNT 11:30AM TO 1:30PM PM COUNT 4:00PM TO 6:00PM



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035
 Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com

VEHICLE TURNING MOVEMENT COUNT

#001 14th St & Bush Avenue - AM PEAK

LOCATION#: 001
 NORTH / SOUTH: 14th St
 EAST / WEST: Bush Avenue

QTD PROJ#: 100158
 DATE: Thursday, September 23, 2010
 VICINITY: San Pablo, CA

DIRECTION:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	TOTALS
LANES:	0	0	0	0	1	0	0	1	0	0	1	0	
6:00 AM													
6:15 AM													
6:30 AM													
6:45 AM													
7:00 AM	0	0	0	1	0	1	0	1	0	0	5	0	8
7:15 AM	0	0	0	1	0	1	2	2	0	0	5	2	13
7:30 AM	0	0	0	0	0	1	4	3	0	0	4	0	12
7:45 AM	0	0	0	4	0	1	1	4	0	0	4	1	15
8:00 AM	0	0	0	4	0	3	0	4	0	1	4	0	16
8:15 AM	0	0	0	5	0	2	1	1	0	0	3	1	13
8:30 AM	0	0	0	0	0	1	1	7	0	0	8	4	21
8:45 AM	0	0	0	2	0	3	2	2	0	0	2	1	12
9:00 AM													
9:15 AM													
9:30 AM													
9:45 AM													
10:00 AM													
10:15 AM													
10:30 AM													

VOLUME STATS:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	
TOTAL:	0	0	0	17	0	13	11	24	0	1	35	9	110
P.H.V: ₁	0	0	0	13	0	7	3	16	0	1	19	6	65
P.H.F: ₂	_____	0.000	_____	_____	0.714	_____	_____	0.594	_____	_____	0.542	_____	0.774

- (1) Peak Hour Volume (Peak Hour Begins At 745 AM)
- (2) Peak Hour Factor (directional aggregate)



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035
 Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com

VEHICLE TURNING MOVEMENT COUNT

#001 14th St & Bush Avenue - MD PEAK

LOCATION#: 001
 NORTH / SOUTH: 14th St
 EAST / WEST: Bush Avenue

QTD PROJ#: 100158
 DATE: Thursday, September 23, 2010
 VICINITY: San Pablo, CA

DIRECTION:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	TOTALS
LANES:	0	0	0	0	1	0	0	1	0	0	1	0	
10:45 AM													
11:00 AM													
11:15 AM													
11:30 AM	0	0	0	0	0	0	0	2	0	0	2	0	4
11:45 AM	0	0	0	2	0	2	2	4	0	0	0	0	10
12:00 PM	0	0	0	2	0	1	0	4	0	0	2	1	10
12:15 PM	0	0	0	1	0	2	1	2	0	0	2	2	10
12:30 PM	0	0	0	0	0	2	0	4	0	0	1	0	7
12:45 PM	0	0	0	2	0	1	0	5	0	0	2	0	10
1:00 PM	0	0	0	1	0	2	1	2	0	0	1	0	7
1:15 PM	0	0	0	1	0	0	0	3	0	0	0	0	4
1:30 PM													
1:45 PM													
2:00 PM													
2:15 PM													
2:30 PM													
2:45 PM													
3:00 PM													
3:15 PM													
3:30 PM													
3:45 PM													

VOLUME STATS:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	
TOTAL:	0	0	0	9	0	10	4	26	0	0	10	3	62
P.H.V: ₁	0	0	0	5	0	6	1	15	0	0	7	3	37
P.H.F: ₂	_____	0.000	_____	_____	0.917	_____	_____	0.800	_____	_____	0.625	_____	0.925

(1) Peak Hour Volume (Peak Hour Begins At 1200 PM)

(2) Peak Hour Factor (directional aggregate)



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035

Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com

VEHICLE TURNING MOVEMENT COUNT

#001 14th St & Bush Avenue - PM PEAK

LOCATION#: 001
 NORTH / SOUTH: 14th St
 EAST / WEST: Bush Avenue

QTD PROJ#: 100158
 DATE: Thursday, September 23, 2010
 VICINITY: San Pablo, CA

DIRECTION:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	TOTALS
LANES:	0	0	0	0	1	0	0	1	0	0	1	0	
3:00 PM													
3:15 PM													
3:30 PM													
3:45 PM													
4:00 PM	0	0	0	2	0	1	6	4	0	0	3	2	18
4:15 PM	0	0	0	5	0	3	1	4	0	0	6	3	22
4:30 PM	0	0	0	4	0	1	4	8	0	0	4	3	24
4:45 PM	0	0	0	4	0	4	2	11	0	0	2	0	23
5:00 PM	0	0	0	3	0	3	4	9	0	0	2	2	23
5:15 PM	0	0	0	0	0	3	4	5	0	0	2	1	15
5:30 PM	0	0	0	4	0	6	2	2	0	0	5	1	20
5:45 PM	0	0	0	9	0	6	7	5	0	0	4	2	33
6:00 PM													
6:15 PM													
6:30 PM													
6:45 PM													

VOLUME STATS:	NL	NT	NR	SL	ST	SR	EL	ET	ER	WL	WT	WR	
TOTAL:	0	0	0	31	0	27	30	48	0	0	28	14	178
P.H.V: ₁	0	0	0	16	0	11	11	32	0	0	14	8	92
P.H.F: ₂	_____	0.000	_____	_____	0.844	_____	_____	0.827	_____	_____	0.611	_____	0.958

- (1) Peak Hour Volume (Peak Hour Begins At 415 PM)
- (2) Peak Hour Factor (directional aggregate)



QUALITY TRAFFIC DATA, LLC

9701 W Pico Blvd, Suite 205, Los Angeles, CA 90035
 Phone: 310-341-0019 Fax: 310-807-9247 Info@QualityTrafficData.com